



Turn Table TR series

- ▲ Turntable are to be placed on top, handle must to be attached.
- ▲ Holding while roller skate is moving, minimum turning radius is 3m.





TR40

TR20


i-Lift No.	1910901	1910902	1910903	1910904	1910905
Model	TR10	TR20	TR30	TR40	TR50
A (mm)(in.)	220(8.7)	250(10)	275(10.8)	360(14.2)	
B (mm)(in.)	74(2.9)	86(3.4)	95(3.7)	114(4.5)	128(5)
C (mm)(in.)	41(1.6)	46(1.8)	64(2.5)		
ΦD (mm)(in.)	128(5)	150(6)	190(7.5)	220(8.7)	
E (mm)(in.)	11(0.4)				
F (mm)(in.)	8(0.3)			3(0.1)	
G (mm)(in.)	88(3.5)	105(4.1)	165(6.5)	235(9.3)	
I (mm)(in.)	5(0.2)		11(0.4)		
Wt. kg(lb.)	4.5(9.9)	6.7(14.7)	13.7(30)	18.9(41.6)	

Packing Plate PC series

- ▲ Packing plate for compensating the difference in height between skates with turntable and the one without turntable.


PC40

PC10


i-Lift No.	1911001	1911002	1911003	1911004	1911005
Model	PC10	PC20	PC30	PC40	PC50
A (mm)(in.)	153(6)	175(6.9)	270(10.6)	350(13.8)	
B (mm)(in.)	74(2.9)	86(3.4)	95(3.7)	114(4.5)	128(5)
C (mm)(in.)	37(1.5)	45(1.8)	61(2.4)		
D (mm)(in.)	120(4.7)	130(5.1)	180(7.1)	200(8)	
F (mm)(in.)	8(3.5)		3(0.1)		
G (mm)(in.)	88(3.5)	105(4.1)	165(6.5)	235(9.3)	
I (mm)(in.)	5(0.2)		11(0.4)		
Wt. kg(lb.)	3.7(8.1)	5.3(11.7)	13.8(30.4)	18.8(41.4)	